



Rollershield Drainage CIFS® – Continuously Insulated Section 07 24 19



Master Wall Inc.®
PO Box 397
Fortson, GA 31808
706-569-0092
800-755-0825
www.masterwall.com

Master Wall Guide Specification RDCIFS Rollershield Drainage CIFS® Wood Grain Add In Specification

2.03 COMPONENTS

L. Specialty Finishes

1. CIFS® Wood Grain System
 - a. CIFS® Wood Grain Tex
 - b. CIFS® Wood Grain Glaze
 - c. CIFS® Wood Grain Sealer

PART III – EXECUTION

K. CIFS® Wood Grain System

1. CIFS® Wood Grain Tex Application
 - a. Using a Wind-Lock T-VPF2008, T-VPF2411 or T-VPF2812 Stainless Steel Venetian Plaster Trowel apply a very tight, thin coat of Wood Grain Tex to the surface free of trowel marks. Use moderate to high pressure with a trowel angle of about 600 to 800 to the wall surface. The amount of material applied to the wall surface is paper thin. Allow the Wood Grain Tex to take up for 2-3 hours or until fully set up. Clean the surface to remove any dust.
 - b. Apply a paper-thin second coat of Wood Grain Tex using short strokes. Allow product to tack up for 10- 15 minutes, then wet trowel using a spray bottle and plaster trowel.
 - c. Once fully dry, sand in the direction of the grain with 100-grit sandpaper to create a level surface and add some imperfections.
 - d. Application problems occur when Wood Grain Tex is applied too thick. Only paper thin applications are necessary.
 - e. Surface may be coated after 24 hours with Master Wall® Wood Grain Sealer. Follow individual data sheet instructions for products selected.
2. CIFS® Wood Grain Glaze Application
 - a. Wood Grain Glaze is applied by brush or a moist foam roller.
 - b. Using a paint brush for latex paints, brush Wood Grain Glaze into the grooves of the finish.
 - c. Using a moist foam roller, roll a thin amount of Wood Grain Glaze onto the finish surface and keep a wet edge.
 - d. Using a spray bottle, wet the surface of the Wood Grain Glaze to thin and keep from tacking too quickly.
 - e. Add grain to the surface using the Wood Grain Tool along the length of the grooved finish, rocking the tool to create the desired pattern.
 - f. Once dry to the touch, lightly sand the surface if needed using 100-grit sandpaper to remove any high spots or heavy stain areas.



Rollershield Drainage CIFS® – Continuously Insulated Section 07 24 19

3. CIFS® Wood Grain Sealer Application

- a. Wood Grain Sealer can be applied by brush, roller, or airless spray equipment. When using a roller, a sponge roller is recommended. Apply Wood Grain Sealer in an even, continuous coat, maintaining a wet edge. Wood Grain Sealer will apply milky white and dry clear.

Disclaimer

This Specification is published for general informational purposes only and is not intended to imply that these are the only materials, procedures, or methods, which are available or suitable. Materials, procedures, or methods may vary according to the particular circumstances, local building code requirements, design conditions, or statutory and regulatory requirements. While the information in this specification is believed to be accurate and reliable, it is presented without guarantee or responsibility on the part of Master Wall Inc.®